




Revenue Control Inspector

MOVie
Emulation

Mobile Oyster Viewer (MOVie)



Button

1. Information

2. Read

3. Next

4. Last

5. L.E.D indicator

6. Screen

7. Charging port

8. Software update port

Function

Provides more information e.g. product price

To read Oyster card details

Moves forward to next screen

Retrieves information of the last Oyster card read

Indicates when there is a possible problem with oyster card

To view information

To recharge Movie

To upgrade Movie software

Switching on MOVie device

To switch the MOVie device on press the read button

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “read”



Reading an Oyster card

To read an Oyster card place the Oyster card on the underside of the MOVie reader and press read

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- Select “read”



No Oyster cards

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function



Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Select “next”

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



History

Screen shot 1

This screen shows a unstated journey which ended at Earls court station, because the customer failed to validate the Oyster card at the start of their journey a maximum fare of £4.00 is charged.

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Screen shot 2

This screen shows a completed journey which started at Earls court station, and ended at Fulham Broadway station. This information is stored in history slot 2. Note no fare is charged due to the fact that a zone 2-6 capping (“CD”) has been achieved

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Screen shot 3

This screen shows a completed journey which started at Barons court station and ended at Earls court station.

This information is stored in history slot 3.

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Screen shot 4

This screen shows a completed journey which started at Hammersmith station on the district line side and ended at Barons court station, This information is stored in history slot 4. Note that only 10p is charged for this journey, because a zone 2-6 capping has been achieved

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Screen shot 5

This screen shows a completed journey which started at Stanford brook station and ended at Ravenscourt Park Station.

This information is stored in history slot 5
The fare charge for this journey is a £1.00

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Screen shot 6

This screen shows a completed journey which started at Turnham Green station, and ended at Stanford Brook Station.

This information is stored in history slot 6. The fare charge for this journey is a £1.00

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Screen shot 7

This screen shows a completed journey which started at Barons Court station and ended at Turnham Green Station.

This information is stored in history slot 7
The fare charge for this journey is a £1.00

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Screen shot 8

This screen shows an completed journey which started at West Kensington station, and ended at Barons Court Station.

This information is stored in history slot 8. The fare charge for this journey is a £1.00

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Travel card details

This screen shows a zone 2-4 travelcard valid from 08NOV06 to 14NOV06, which is loaded in slot 1. “P” indicates that pay as you go has also been loaded onto this Oyster card.

Select “read” first.

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Pay As You Go

This screen shows the current pay as you go balance. Time, date, station where pay as you go was loaded and the amount

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



Un-started journey

This screen shows an un-started journey which ended at Earls Court station. Since the journey is un-started the max fare has been charged

Button options

- **info** no function
- **last** no function
- **read** to switch MOVie device on
- **next** no function
- select “next”



If you continue pressing the next button the screens will loop back to the first read screen, and no further information can be obtained, to check the Oyster card history you must read the Oyster card again

Place Oyster card on the underside of the MOVie reader and press “read”





Travelcard details

This screen shows travelcard details, **PASS** indicates travelcard purchased from pass agent and **£18.40** is the amount paid.

Button options

info no function

last no function

read to switch MOVie device on

next no function



Sub-total

Button options

info no function

last no function

read to switch MOVie device on

next no function



Sub-total

Button options

info no function

last no function

read to switch MOVie device on

next no function



oyster™

Oyster
10 july 07
13:27
LUL&DLR/NO-Z

info

last

read

next



oyster™

Oyster
10 july 07
13:27
LUL&DLR/NO-Z

info

last

read

next

oyster™

Oyster
10 july 07
13:27
LUL&DLR/NO-Z

info

last

read

next



oyster™

Oyster
10 july 07
13:27
LUL&DLR/NO-Z

info

last

read

next



oyster™

Oyster
10 july 07
13:27
LUL&DLR/NO-Z

info

last

read

next

oyster™

Oyster
10 july 07
13:27
LUL&DLR/NO-Z

info

last

read

next

oyster™

Oyster
10 july 07
13:27
LUL&DLR/NO-Z

info

last

read

next



oyster™

Oyster
10 july 07
13:27
LUL&DLR/NO-Z

info

last

read

next



